



Automatic Operation Setup and Changes

Note: Set the Function switch to the Set Programs position to make changes. When finished, return the Function switch to the Run position and the Dial to the Current Time position.

- **Set Current Time:** With Dial set to Current Time, use the +/- buttons to adjust as needed.
- **Set Current Day:** Turn Dial to Today. Use the +/- buttons to adjust the day abbreviation.
- **Set Valve Run Time:** Turn the Dial to the valve number to adjust. Use the +/- buttons to adjust the run time from 1–59 minutes, 1 – 5.9 hours or OFF.
- **Set Watering Day Schedule:** Set the Program switch to select Program A, B or C.
 - **Weekday Schedule:** Turn the Dial to the desired day position. Use the +/- buttons to select ON or OFF for the day. Repeat as needed for all weekdays.
 - **Skip Days:** Turn the Dial to Skip Days. Use the +/- buttons to select Once Every 01–31 days. Turn Dial to Today. Use the +/- buttons to select the current day of the interval.
 - **Odd/Even Date:** Turn the Dial to Skip Days. Press Manual button repeatedly to display (– – –). Use the +/- buttons to select Odd or EVn (Even) schedule.
 - **Set Exclusion Days** (Odd/Even or Skip Days schedule only): Turn the Dial to the day to be excluded. Press the + or – button to display OFF.
- **Select Program Start Time(s):** Turn the Dial to Start Time position 1, 2 or 3. Use the +/- buttons to set the start time or turn the start time OFF (one increment past 11:59 or 5:59 (AM or PM)).

Manual Operations

Semi-Automatic Operation– To manually run the watering cycle of a selected Program:

Set the Function switch to Run, and the Dial to Current Time.

Set the Program switch to select **A, B or C**.

Press the **Semi-Auto** button to start the watering cycle.

- Press the Manual button to step through the station sequence.
- To terminate operation, momentarily place the Function switch in the OFF position.

Station Operation – To manually operate selected stations for a specific run time:

Set the Function switch to Run.

Turn the Dial to the selected station number.

Use the +/- buttons to select a run time.

Press the Manual button to start the operation.

- To start and/or stack additional stations for manual operation, repeat the procedure.
- Press the Manual button to step through the station sequence.
- To terminate operation, momentarily place the Function switch in the OFF position.

Rain Delay

With Dial set to Current Time, place the Function switch to the OFF position.

Press the + button to set 1 to 9 delay days (**OF 1 – OF 9**).

Cancel Rain Delay by pressing the + or – button to get below the **OF 1** or above the **OF 9** position.



WATERING SCHEDULE

Valve Run Times				
Valve No.	A Program	B Program	C Program	Valve Location
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
Program	Start Times			Watering Days
	1st	2nd	3rd	
A				
B				
C				